



OWNER'S MANUAL
Electric Models

Model No. _____
Serial No. _____



BENKO PRODUCTS INC.

5350 Evergreen Pkwy, Sheffield Village, Ohio 44054 (440)934-2180 FAX(440)934-4052
www.benkoproducts.com e-mail: info@benkoproducs.com

CONTENTS

- I. WARRANTY
- II. SECTION 1 - INTRODUCTION
Receiving and Safety
- III. SECTION 2 - INSTALLATION
- IV. SECTION 3 - OPERATING INSTRUCTIONS
- V. SECTION 4 - REPLACEMENT PARTS
- VI. SECTION 5 - OPTIONAL EQUIPMENT
INFORMATION

WARRANTY

Benko Products Inc. warrants to customer that all new equipment is free from defect in workmanship and material as of time and place of delivery. Subject to the conditions herein, Benko will repair or replace, without charge, any parts proven to Benko Products' satisfaction to have been defective. Claims must be made within two years after date of shipment. Benko Products will not repair or replace any parts that become defective due to improper use or abuse.

Equipment and accessories not of Benko Products' manufacture are warranted only to the extent that they are warranted by the manufacturer, and only if the claimed defect arose during normal use, application and service. Equipment which has been altered or modified by anyone, without Benko Products' written authorization, is not warranted by Benko Products Inc.

EXCEPT AS STATED HEREIN, BENKO PRODUCTS INC., MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Buyer's exclusive remedy for claims arising hereunder shall be for damages. Benko Products Inc.'s alleged negligence for defective goods, irrespective of whether such defects are discoverable or latent, shall in no event exceed the cost to Benko Products Inc. of repairing, at Benko Products option, the defective or damaged goods. In no event, including in the case of a claim of negligence, shall Benko Products Inc. be liable for incidental or consequential damage.

SECTION 1 - INTRODUCTION

1-1 GENERAL

This manual has been prepared for use in familiarizing personnel with the design, installation, operation, and maintenance of the Drum Warming Oven. Information presented herein should be given careful consideration to assure safe, optimum performance of this equipment.

1-2 RECEIVING/HANDLING

Prior to installation of the equipment, remove packaging material around unit and carefully inspect for any damage that may have occurred during shipment. Remove optional accessories from inside the Drum Warming Oven and inspect these for damage also. Any claims for loss or damage that may have occurred in transit must be filed by the purchaser with the carrier.

1-3 SAFETY - ELECTRIC DRUM WARMING OVEN

CAUTION: The Sahara Electric Drum Warming Oven should not be used to heat flammable or combustible materials or used in flammable or hazardous areas.

CAUTION: The Hot Box outer skin temperature may exceed 120 degrees Fahrenheit. Prolonged contact may result in bodily injury.

CAUTION: Do not stack Hot Boxes more than two (2) high.

CAUTION: When Hot Box ovens are used for heating materials that may generate hazardous vapors, venting or exhausting of the unit is required. Always open doors slowly and avoid breathing the air from inside the unit.

SECTION 2 - INSTALLATION

2-1 LEVELING

IMPORTANT: To ensure proper closing and alignment of doors, the Hot Box must be set on a level floor.

2-2 ELECTRIC CONNECTIONS

Connect power to electrical control enclosure. Reference electrical schematic located inside control enclosure.

2-3 TEMPERATURE SETTING

Set desired temperature. See operating instructions section of manual.

2-4 OVERTEMPERATURE SETTING

The Hot Box is equipped with a high temperature cutoff. The high temperature cutoff adjustment is located inside the electrical control enclosure.

CAUTION: DO NOT ENTER DISCONNECT OR CONTROL ENCLOSURES WITHOUT SHUTTING OFF POWER TO THE UNIT. INSTALLATION AND ADJUSTMENT OF CONTROLS SHOULD BE MADE BY A QUALIFIED ELECTRICIAN.

SECTION 3 - OPERATING INSTRUCTIONS

SAHARA HOT BOX Ovens utilize a SELF-TUNING FUZZY LOGIC TEMPERATURE CONTROLLER. What this means is that the temperature controller will self-adjust its internal control parameters to match the oven it is attached to. The end result of this self-tuning action is that over time the oven temperature control will become more consistent and will automatically adjust to changing ambient conditions. The user should not find it necessary to make any adjustments to the control parameters.

SET IT AND FORGET IT!!

3-1 OVEN OPERATING INSTRUCTIONS

1. Turn power switch to the “ON” position.
2. Wait about five seconds for the FDC 9100 and the FDC-L91 to cycle through self-test.
3. Once self-test is complete:
 - The upper display on the Temperature Control (FDC 9100) will show the current oven temperature (PV).
 - The lower display on the FDC 9100 will show the oven set point temperature. (Note: when you first turn your oven on this value will usually be 200° F. which is the normal test temperature used at the factory.)
 - The display on the Over Temperature Controller (FDC-L91) will show the current oven temperature (PV).
4. If your oven has a blower option the oven will not heat unless the blower switch is turned to the “ON” position. The green lamp should light and the oven will be heating.
5. If your oven has a 7 Day Timer option you have two modes of operation available:
 - Timer Switch “ON” oven will only operate during the programmed times set in the timer. (See the Omron H2S-B operating manual) you must set the “Time of Day” and select the daily operating “ON and OFF” times for the oven to operate in this mode.
 - Timer Switch “Bypass” the oven will operate continuously.

NOTE: The Omron timer used has two (2) output relays available, however the SAHARA OVEN controls only use output 1 and only time values set for output 1 will control the oven.

3-3 OVER TEMPERATURE CONTROL OPERATING INSTRUCTIONS

1. After the power up sequence is complete the over temperature set point may be changed.
2. Press the SCROLL key once located on the lower left of the FDC-L91 to view the High Set Point 1 (HSP1) value. NOTE: THIS VALUE MUST BE SET AT LEAST 20 DEGREES HIGHER THAN THE OPERATING TEMPERATURE SET POINT SELECTED ON THE TEMPERATURE CONTROLLER (FDC 9100)
3. To change this value use the up and down arrow keys. If the LOCK light is "ON" the "RESET" button must be pressed once to turn the "LOCK" light off and then the arrow keys will work. The FDC-L91 will automatically go back into "LOCK" mode after about 2 minutes.
4. If an over temperature event has occurred (the temperature in the oven exceeds the HSP1 value) the Over Temperature Controller (FDC-L91) will go into an alarm condition and will shut off and lock out the power to the heating elements. The oven will return to room temperature and will not heat up again until the unit is reset.
5. If an over temperature event has occurred, the small green light OP1 will turn on. When OP1 is "ON" the oven will not heat. Once the oven temperature has cooled to below the HSP1 value the RESET key on the lower right of the Over Temperature Controller (FDC-L91) may be pressed once and released. This will turn "OFF" the OP1 indicator and the oven will again begin to heat up.

SECTION 4 - REPLACEMENT PARTS

SAHARA ELECTRIC MODELS

PLEASE STATE MODEL AND SERIAL NUMBER ON FRONT OF MANUAL WHEN ORDERING REPLACEMENT PARTS.

DESCRIPTION

DIGITAL TEMPERATURE CONTROLLER
(FDC 9100)

PID DIGITAL OVER TEMPERATURE CONTROLLER
(FDC-L91)

RIGHT DOOR W/ HINGES

LEFT DOOR W/ HINGES

DOOR GASKET REPLACEMENT KIT

CAUTION DECAL REPLACEMENT KIT

RESISTANCE HEATING ELEMENT